
How To Program A Comcast Remote

*How To
Program A
Comcast
Remote*

*Downloaded
from
remodelicious.com
by Evie & Yates*

INTRODUCTION: UNLOCK THE FULL POTENTIAL OF YOUR COMCAST REMOTE

Your Comcast Xfinity remote is more than just a channel changer. It is a powerful control hub for your television, sound system, and streaming devices. However, to enjoy its full range of features, you need to program it correctly. Whether you have just moved into a new home, replaced your TV, or bought a new remote,

understanding **how to program a Comcast remote** is essential for a seamless entertainment experience. In this comprehensive guide, we will walk you through every method available, from automatic pairing to manual code entry, and cover the most common troubleshooting scenarios. By the end, you will be able to master your remote in just a few minutes.

IDENTIFYING YOUR COMCAST REMOTE MODEL

Before diving into the

programming steps, it is important to know which Comcast remote you own. The two most common models are the **XR15** (voice remote) and the **XR11** (older voice remote), along with the standard infrared remotes. Each model has slightly different programming steps, so take a moment to check your remote's label or look for the model number inside the battery compartment.

XR15 Voice Remote

This is the latest Xfinity voice remote. It features a dedicated microphone button, a Netflix button, and a

streamlined design. It connects to your Xfinity box via Bluetooth and to your TV via infrared or HDMI-CEC.

XR11 Voice Remote

The XR11 also has voice control but uses a different pairing process. It pairs to the Xfinity box via RF (radio frequency) and to the TV via IR.

Standard Infrared Remote

Older Comcast remotes (like the silver or black universal remotes) operate solely via

infrared. They require a direct line of sight to the device and must be programmed manually using code lists.

HOW TO PROGRAM A COMCAST REMOTE TO YOUR XFINITY TV BOX

The first step in programming your remote is ensuring it communicates with the main Xfinity box. For voice remotes, this is typically an automatic process once you insert batteries. For older remotes, you may need to manually link them.

Automatic C Program

Programming for XR15 and XR11 Remotes

1. **Insert batteries** (two AA or AAA, depending on model).
2. Turn on your Xfinity TV box.
3. Wait for the remote's LED light to blink and then stay solid. This indicates the remote has paired via Bluetooth (XR15) or RF (XR11).
4. If the LED continues to blink for more than 60 seconds, hold the **Setup** button (if available) or

press and hold the **Pair** button (usually under the battery cover) for 3 seconds.

Manual Pairing for Older Infrared Remotes

If your remote does not have a Bluetooth or RF option, you must configure it to control the Xfinity box by entering a code:

1. Turn on the Xfinity box.
2. Press and hold the **Setup** button until the LED at the top of the remote

changes from red to green.

3. Press the **Xfinity** button (or the button that corresponds to your box).
4. Enter a code from the **Comcast remote code list** (you can find these online or in the manual). For most boxes, code **0247** or **0172** works.
5. The LED will blink green twice to confirm. Test the remote by pressing the Power or Guide button.

PROGRAMMING YOUR COMCAST REMOTE TO CONTROL THE TV

Once your remote works with the Xfinity

box, you need to program it to adjust your TV's volume, power, and input. This can be done automatically using the remote's scanning function or manually by entering a code.

Using Auto- Scan (Recommended for how to program a

Comcast remote for a TV)

1. Turn on your TV manually or using its original remote.
2. On your Comcast remote, press the **TV** button once.
3. Press and hold the **Setup** button until the LED blinks twice.
4. Enter **9-9-1** (the auto-scan command). The LED will blink twice again.
5. Press the **Power** button repeatedly (once per second) until the TV turns off. This may take up to 200 presses.

6. Once the TV turns off, immediately press the **Setup** button to lock in the code. The LED will blink twice.
7. Test the Volume and Mute buttons to ensure they work. If not, repeat the process starting from step 2.
1. Press the **TV** button.
2. Hold the **Setup** button until the LED blinks twice.
3. Enter a five-digit code from the Comcast remote TV code list. For example, **10030** works for many Samsung TVs, **10178** for LG, and **10056** for Sony.
4. The LED will blink twice. Test by pressing Power, Volume, and Mute.

Manual Code Entry for TV Controls

If you know your TV brand, you can enter a specific code instead of scanning:

PROGRAMMING YOUR COMCAST REMOTE FOR A SOUNDBAR OR AV RECEIVER

If you have an external audio system, you can set your remote to control its volume. The process mirrors the TV

program but uses the **Aux** or **Audio** button.

1. Press the **Aux** button on the remote.
2. Hold the **Setup** button until the LED blinks twice.
3. Enter the code for your soundbar brand (e.g., **30000** for many Vizio soundbars, **30020** for Bose).
4. The LED will blink twice. Test volume and power.

If you do not have a code, use the auto-scan method as described above, but press the **Aux** button instead of the **TV** button before entering **9-9-1**.

HOW TO PROGRAM

REMOTE FOR VOICE CONTROL

Voice remotes like the XR15 allow you to search for shows, change channels, and launch apps by speaking. To enable voice control, you must first complete the Bluetooth pairing with the Xfinity box. Follow these steps:

1. Make sure your Xfinity box is on and connected to Wi-Fi.
2. Press and hold the **Microphone** button on the remote.
3. Say "Pair remote" or "Setup voice control."
4. Follow the on-screen prompts on your TV. The box will confirm pairing.

5. If the remote does not respond to voice commands, try performing a factory reset (see troubleshooting below).

PROGRAMMING YOUR COMCAST REMOTE TO CONTROL STREAMING DEVICES (ROKU, APPLE TV, ETC.)

Many Comcast remotes can also control streaming devices connected via HDMI. This feature is called **HDMI-CEC** and works automatically with the XR15 remote if your TV supports it. For older remotes, you may need to program the device using the **Aux** button:

1. Press the **Aux** button.

2. Hold the **Setup** button until the LED blinks twice.
3. Enter the code for your streaming device. For Roku, try **30224** or **31756**. For Apple TV, use **31759**.
4. The LED will blink twice. Test directional pad and select buttons.

TROUBLESHOOTING COMMON PROGRAMMING ISSUES

Even with clear instructions, you may run into problems. Here are solutions to the most frequent issues when learning **how to program a Comcast remote**.

Remote LED not Blinking

- Replace batteries with fresh ones.
- Check battery polarity.
- Remove any objects blocking the IR sensor.

TV Volume or Power Not Working After

Program ming

- TV may require a different code. Repeat auto-scan and be patient – the correct code may be toward the end of the database.
- Ensure the remote is set to **TV** mode before pressing Volume or Power.
- If you have a soundbar, make sure the remote is in **Aux** mode when controlling volume.

Voice Comman

ds Not Working

- Confirm the remote is paired via Bluetooth. Press the **Microphone** button – if the LED flashes red, it is not paired.
- Reboot your Xfinity box by unplugging it for 30 seconds.
- Reset the remote: remove batteries, press every button for 3 seconds, reinsert batteries, and re-pair.

Remote

Still Does Not Work After Programming

- Try a **factory reset**: For XR15, press and hold the **Exit** and **Info** buttons together for 5 seconds, then release. The LED will blink green. Then re-pair. For XR11, remove batteries, press and hold the **Power** button for 10 seconds, reinsert batteries, and pair again.
- Contact Comcast support for a

replacement if the remote is damaged.

FINDING ADDITIONAL CODES AND RESOURCES

If the codes mentioned above do not work for your specific device, Comcast provides an updated code database on their website. You can also use the Xfinity mobile app to program your remote digitally – simply open the app, select **Remote Control**, and follow the guided setup. This method is particularly useful if you have lost the original code list.

CONCLUSION

Programming your Comcast remote does not have to be a frustrating experience.

By following the steps outlined in this guide, you can confidently control your TV, sound system, and streaming devices with a single device. Whether you are using the newest XR15 voice remote or an older infrared model, the techniques for **how to program a Comcast remote** are straightforward once you understand the basics of pairing, auto-scanning, and manual code entry. Remember to stay patient during the auto-scan process, as it may take a minute to find the correct code. With a properly programmed remote, you can say goodbye to juggling multiple controllers and enjoy the convenience of a unified home entertainment system.