

Jawbone Mini Jambox User Guide

Jawbone Mini Jambox User Guide

Downloaded from remodelicious.com by Osborn & Michaela

GETTING STARTED WITH YOUR JAWBONE MINI JAMBOX: A COMPLETE USER GUIDE

Welcome to your comprehensive Jawbone Mini Jambox user guide. Whether you have just unboxed this compact Bluetooth speaker or are looking to refresh your memory on its features, this article will walk you through every step. The Jawbone Mini Jambox is a portable, wireless speaker known for its impressive sound quality and stylish design. In this guide, we will cover setup, pairing, controls, advanced features, battery care, and troubleshooting. By the end, you will feel confident using your speaker to its full potential.

Unboxing the Jawbone Mini Jambox

Inside the box you will find the Jawbone Mini Jambox speaker, a micro USB charging cable, an audio cable (3.5mm auxiliary), and a quick start guide. Before using the speaker, ensure it is fully charged. Connect the micro USB cable to the speaker and a USB power source. The LED indicator will glow red while charging and turn white when fully charged. A full charge typically takes about 2.5 hours and provides up to 10 hours of playback time.

Powering On and Off

To turn on the Jawbone Mini Jambox, press and hold the power button (located on the top edge) for about two seconds until you hear a startup tone. To turn it off, press and hold the same button until you hear a descending tone. The LED will blink white when the speaker is on and ready to pair. If the speaker is idle for 15 minutes, it automatically powers off to save battery.

Pairing Your Device via Bluetooth

1. **Enable Bluetooth** on your smartphone, tablet, or computer.
2. **Turn on the speaker** by pressing the power button until the LED blinks white.
3. **Wait for the speaker** to appear in your device’s Bluetooth list as “Jawbone Mini Jambox.” If it does not appear, press the Bluetooth button (the button with the Bluetooth icon) on the speaker to make it discoverable.
4. **Select the speaker** from the list. You may hear a confirmation tone, and the LED will glow solid white once connected.

The Jawbone Mini Jambox uses Bluetooth 4.0, offering a range of approximately 33 feet (10 meters) in open environments. It can remember up to eight previously paired devices and connect to two devices at the same time, allowing you to switch between phone calls and music playback seamlessly.

Using the Controls

The top of the speaker houses all physical buttons. The central button is the multi-function **Talk/Play** button. Use it to play or pause music, answer or end calls, and activate voice control. The outer ring has volume up (+) and volume down (-) buttons. To skip to the next track, press and hold the volume up button; to go to the previous track, press and hold the volume down button. The power button is on the far left, and the Bluetooth button on the far right.

For speakerphone use, the Jawbone Mini Jambox includes a noise-canceling microphone. When a call comes in, press the Talk/Play button to answer. Press it again to end the call. To reject an incoming call, press and hold the Talk/Play button for two seconds. You can also initiate a call by pressing the Talk/Play button when the speaker is connected to a phone that supports voice commands (like Siri or Google Now).

Understanding the LED Indicators

- **Solid white** – Connected and ready.
- **Blinking white** – Pairing mode or searching for device.
- **Red blinking** – Low battery (below 15%).
- **Solid red while charging** – Battery charging.
- **Solid white while charging** – Fully charged.
- **Amber blinking** – Firmware update in progress (via the Jawbone app).

Jawbone Mini Jambox App and Firmware Updates

Jawbone offers a free app for iOS and Android called **Jawbone** (previously known as MyTALK). Download it from the App Store or Google Play. The app allows you to:

- Update the firmware of your Mini Jambox.
- Customize voice alerts and button functions.
- Manage paired devices.
- Access a “Find My Speaker” feature.

To update the firmware, open the app while the speaker is connected via Bluetooth. The app will check for updates and guide you through the process. Firmware updates can improve battery performance, audio quality, and fix bugs.

Using the Auxiliary Input

If your device does not have Bluetooth or you prefer a wired connection, use the included 3.5mm audio cable. Plug one end into the speaker’s AUX port (hidden under the rubber flap on the front) and the other end into your device’s headphone jack. The speaker will automatically switch to AUX mode when a cable is inserted. Note that the volume must be controlled from the connected device when using the auxiliary input; the speaker’s volume buttons will not work in this mode, though the Talk/Play button still functions for calls if the speaker is also paired via Bluetooth.

Optimizing Sound: LiveAudio and Speaker Positioning

The Jawbone Mini Jambox features **LiveAudio** technology, which simulates a wider soundstage. To enable LiveAudio, press and hold both volume buttons (up and down) simultaneously for two seconds. You will hear a tone, and the sound will become more spacious. Press and hold again to disable. LiveAudio works best when the speaker is placed at ear level, facing you. The speaker also uses a passive bass radiator on the back; for deeper bass, place it near a wall or on a reflective surface.

Battery Management and Charging Tips

The built-in lithium-ion battery is non-removable. For optimal battery life:

- Charge the speaker using the provided cable and a standard USB charger (5V/1A). Using a high-current charger (like a tablet charger) may charge faster but is also safe.
- Avoid exposing the speaker to extreme temperatures (below 0°C or above 45°C).
- If you don’t use the speaker for several months, charge it to about 50% and store in a cool, dry place.
- The battery runtime (up to 10 hours) depends on volume level and usage of LiveAudio. At maximum volume, battery life may drop to about 6 hours.

To check battery status: press the power button briefly while the speaker is on. The LED will flash red (low), amber (medium), or white (high). Alternatively, the Jawbone app will show a precise battery percentage.

Cleaning and Maintenance

The exterior of the Jawbone Mini Jambox is made of a rubberized material that can attract dust and lint. Clean it with a soft, slightly damp cloth. Do not use harsh chemicals or abrasive cleaners. The speaker is splash-resistant but not waterproof; avoid submerging it. The metal grille can be gently wiped clean. If the charging port becomes clogged, use a toothpick or compressed air carefully. The rubber flap covering the ports should be kept closed when not in use to prevent debris ingress.

Troubleshooting Common Issues

SPEAKER NOT TURNING ON

Ensure the battery is charged. Connect to a charger and wait a few minutes. If still no response, try resetting the speaker: press and hold the power

button and the Talk/Play button simultaneously for 10 seconds until the LED flashes red and white. This resets the speaker to factory defaults.

CANNOT CONNECT VIA BLUETOOTH

First, clear the speaker’s pairing memory: hold the Bluetooth button for 10 seconds until the LED blinks rapidly. Then re-pair as a new device. Also, make sure your phone’s Bluetooth is on and that the speaker is not connected to another device. If problems persist, restart both devices.

AUDIO STUTTERING OR SKIPPING

Move the source device closer to the speaker. Interference from other wireless devices (Wi-Fi routers, microwaves) can cause dropouts. Reduce the number of devices connected to the same speaker. If using through a wall, try a direct line of sight.

MICROPHONE NOT WORKING DURING CALLS

Check that the speaker is selected as the audio output device on your phone during the call. On some phones, you may need to manually switch to the Bluetooth device. Also, ensure the rubber flap covering the microphone (small hole near the front) is not blocked.

NO SOUND FROM AUXILIARY INPUT

Make sure the 3.5mm cable is fully inserted. Verify that the cable is not damaged. Some devices require you to adjust the volume on both the source and the speaker (though the speaker buttons are disabled in AUX mode, volume can be controlled from the source). If you recently used Bluetooth, switch the source back to AUX manually if needed.

Resetting the Jawbone Mini Jambox to Factory Settings

1. Turn on the speaker.
2. Press and hold both the Power button and the Talk/Play button simultaneously for about 10 seconds.
3. Release the buttons when you see the LED flash red and white.
4. The speaker will turn off. Turn it back on; all paired devices will be erased.

This is useful if you are giving away the speaker or if you experience persistent pairing issues.

Using Multiple Jawbone Mini Jambox Speakers (Party Mode)

The Jawbone Mini Jambox does not support true multi-speaker pairing like some newer speakers. However, you can connect two Mini Jambox speakers to separate audio sources or use a splitter cable with the auxiliary input. There is no official feature to link two speakers wirelessly for stereo or party

mode.

Compatibility with Devices

The Jawbone Mini Jambox works with any Bluetooth-enabled device that supports the A2DP profile for audio streaming and HFP for hands-free calling. This includes iPhones, iPads, Android smartphones and tablets, Windows computers, Macs, and some smart TVs. For devices without Bluetooth, the auxiliary input is available. The speaker is also compatible with voice assistants like Siri, Google Assistant, and Cortana, provided the host device supports them.

Frequently Asked Questions

CAN I USE THE JAWBONE MINI JAMBOX WHILE CHARGING?

Yes, you can use it while plugged in. The speaker will still play audio, but the battery charging time may be slightly longer if used at high volume.

DOES THE SPEAKER HAVE A BUILT-IN EQUALIZER?

No physical EQ, but LiveAudio provides a simulated surround effect. The Jawbone app does not offer an EQ either. You can adjust bass and treble from your source device’s music app if available.

HOW DO I UPDATE THE FIRMWARE WITHOUT THE APP?

The firmware update requires the app. If you no longer have access to the app (e.g., it is discontinued), updates are not possible. The latest firmware version for the Mini Jambox is already on most units. Check Jawbone’s support website for any archived files, but official support ended in 2017.

IS THE JAWBONE MINI JAMBOX WATERPROOF?

No, it is only splash-resistant. Avoid using it in the rain or near pools.

Conclusion

The Jawbone Mini Jambox remains a capable portable Bluetooth speaker even years after its release. Its compact design, decent battery life, and clear sound make it a solid companion for travel, outdoor gatherings, or casual listening. By following this Jawbone Mini Jambox user guide, you can overcome common hurdles and get the most out of your device. Remember to keep the firmware updated, clean the speaker regularly, and store it properly. Enjoy your music and hands-free calls with this well-crafted speaker.