

---

# Nikon D 40 Tips And Tricks

---

*Nikon D 40 Tips And Tricks*

*Downloaded from [remodelicious.com](http://remodelicious.com) by  
Alice & Jillian*

---

## INTRODUCTION: REDISCOVERING THE NIKON D40

---

If you own a **Nikon D40**, you are holding a piece of digital photography history. Introduced in 2006, this compact, 6.1-megapixel DSLR was many photographers' first step into the world of interchangeable-lens cameras. While modern cameras boast higher resolutions and advanced autofocus systems, the D40 remains surprisingly capable, especially for learning the fundamentals. Its lightweight body, intuitive controls, and excellent JPEG engine produce images with pleasing color and contrast. However, to truly unlock its potential, you need a few insider tips. Whether you are a new user dusting off an old camera or a budget-conscious enthusiast, this guide covers essential **Nikon D 40 tips and tricks** that will elevate your photography without requiring a single firmware update.

---

## GETTING THE MOST OUT OF YOUR NIKON D40

---

Before diving into advanced techniques, it helps to understand the D40's strengths and limitations. The camera lacks an internal autofocus motor, so only AF-S and AF-I lenses will autofocus. Yet its small sensor and lack of heavy features mean you can carry it

anywhere. Here are foundational tips to improve daily shooting.

## Optimize Image Quality Settings

Inside the shooting menu, set **Image Quality** to **Fine** and **Image Size** to **Large** (3008×2000 pixels). Although 6.1 MP seems modest by today's standards, a properly exposed fine-quality JPEG or RAW file can produce sharp prints up to 8×10 inches. If you prefer maximum flexibility, shoot in RAW+JPEG Fine. This uses more card space but lets you adjust white balance and exposure later.

## Use the “Noise Reduction” and “Active D-Lighting” Wisely

The D40 includes a **Long Exposure Noise Reduction** option for exposures longer than one second. Keep it turned on when

shooting night scenes. For general use, turning off **Active D-Lighting** often yields more natural contrast; the camera's dynamic range is limited, and Active D-Lighting can cause unnatural shadows. Test with both settings to find your preference.

---

## MASTERING MANUAL AND SEMI-AUTOMATIC MODES

---

One of the best **Nikon D 40 tips and tricks** is to step away from the fully automatic program mode. The D40's **Aperture Priority (A)** and **Shutter Priority (S)** modes are easy to use and give you creative control.

## Aperture Priority for Depth of Field

Set the mode dial to **A**. Use the control wheel to choose an aperture. A wide aperture like f/2.8 (if your lens supports it) blurs the background for portraits. For landscapes, choose f/8 to f/11 to keep everything sharp. Remember that the D40's viewfinder is small, so check the LCD to confirm focus and depth.

## Shutter Priority for Action

## Shots

Switch to **S** when photographing moving subjects. For walking speed, try 1/125 sec; for running children or pets, go to 1/250 sec or faster. The D40's continuous shooting speed of 2.5 frames per second is enough for casual sports. Pair with a fast AF-S lens like the 18-55mm kit lens (set to **AF-A** autofocus) to keep subjects sharp.

## Using Manual Mode Creatively

In **M** mode, you set both aperture and shutter. This is great for consistent exposure when the light doesn't change. Use the built-in exposure meter (a scale in the viewfinder) as a guide. For night photography, set a low ISO (200) and a wide aperture, then adjust shutter speed until the scale reads zero. A tripod is essential because the D40 struggles with high ISO noise above 800.

---

## FOCUS AND LENS COMPATIBILITY TRICKS

---

A common frustration with the D40 is its reliance on lenses with built-in motors. To expand your options without breaking the bank, consider these workarounds.

## Focus with Manual Lenses

Many older Nikon AI-S and Series E lenses are affordable and optically excellent. While the D40 cannot meter with manual lenses, you can **focus manually** and use the **electronic rangefinder**. After mounting a non-CPU lens (using a meter-less adapter if needed), set the camera to **M** mode. Press the **AE-L/AF-L** button to engage the rangefinder: a green dot and arrows in the viewfinder help you confirm focus. It takes practice but yields beautiful results.

## Maximize Kit Lens Performance

The 18-55mm f/3.5-5.6 AF-S kit lens sharpens noticeably when stopped down to f/5.6 at wide angle and f/8 at telephoto. For portraits at 55mm, step back a little and use the widest aperture to get moderate background blur. Use **Single-Area AF** and place the focus point on your subject's eyes.

## Third-Party AF Lenses

Lenses from Tamron and Sigma with built-in motors (e.g., Tamron 18-200mm Di II) autofocus smoothly on the D40. They can be found used for under \$100. This is one of the most practical **Nikon D 40 tips and tricks** to expand your focal range without buying a new body.

---

### USING THE BUILT-IN FLASH CREATIVELY

---

The D40's pop-up flash is often maligned for harsh, flat lighting, but with a few tweaks it becomes surprisingly flexible.

## Reduce Flash Intensity

Press the **Flash** button and spin the control wheel to adjust flash compensation. Dial in -0.7 or -1.0 to prevent blown-out highlights. For fill-flash outdoors, set compensation to -1.3 for natural-looking catchlights.

## Slow Sync and Rear Curtain Sync

In **A** or **P** mode, the camera normally uses front-curtain sync. Switch to **Slow Sync** (using the flash mode button) to combine a long shutter with flash. This blurs ambient light while freezing the subject. For creative night portraits, try **Rear-Curtain Sync** so that motion trails appear behind the subject. Experiment in **S** mode with a shutter speed around 1/15 sec.

---

### WHITE BALANCE AND PICTURE CONTROLS

---

The D40's default white balance (WB) usually gives warm indoor tones. Customizing WB helps avoid color casts and reduces post-production work.

## Custom White Balance

Under mixed lighting, photograph a white piece of paper filling the frame, then navigate to **Shooting Menu > White Balance > Preset Manual > Measure**. Select the image. The D40 will set a custom WB, removing color shifts. This trick is especially valuable when shooting in warm incandescent light or under fluorescent tubes.

## Picture Controls for Direct JPEGs

The D40's **Image Overlay** and **Monochrome** modes are found in the **Set Picture Control** menu. Standard gives good general results. For punchy landscapes, try **Vivid** with added sharpness (+1) and saturation (+1). For portraits, set **Portrait** mode with reduced contrast to smooth skin. Fine-tune these in the **Shooting Menu** under **Picture Control > Adjust**.

---

### TIPS FOR BETTER LOW-LIGHT PHOTOGRAPHY

---

The D40's high-ISO performance is limited—ISO 800 is usable, ISO 1600 is noisy, and ISO 3200 is nearly unusable. Follow these **Nikon D 40 tips and tricks** to make the most of dim scenes.

## Use a Fast Prime Lens

The AF-S 35mm f/1.8G DX is an excellent choice for the D40. It composes like a 50mm on full-frame, and at f/1.8 it gathers much more light than the kit lens. Used copies are affordable. You can shoot at ISO 400 or 800 with faster shutter speeds, keeping images cleaner.

## Bracket for Exposure

Enable **Auto Bracketing** in the shooting menu. Set the bracket to  $\pm 1.0$  EV with three frames. This gives you a choice of darker, normal, and brighter exposures, which you can blend later in software. It's a reliable way to handle tricky high-contrast scenes without noise.

## Use the Self-Timer or a Remote

For tripod shots, enable the self-timer (10 seconds) to avoid camera shake. The D40 accepts an infrared remote (ML-L3) if you want hands-free triggering. With a stable platform and low ISO (200), you can capture clean long-exposure landscapes at night.

---

### SIMPLE COMPOSITION AND POST-PROCESSING

---

Even with basic gear, composition makes the difference. Apply

these practical tips to your D40 workflow.

## Use the Grid Overlay

In the **Setup Menu**, turn on **Grid Display** in the viewfinder. This helps you follow the rule of thirds and keep horizons level. It is a free upgrade to your framing accuracy.

## Shoot RAW and Process with Free Software

While the D40's JPEG engine is good, RAW files contain more tonal information. Use free programs like **Nikon ViewNX-i** (supports D40 NEF files) or **RawTherapee** to adjust exposure, white balance, and noise reduction. A bit of sharpening and careful noise reduction can make ISO 800 images look nearly as

smooth as modern sensors.

---

### CONCLUSION

---

The Nikon D40 may be a vintage camera, but it remains a brilliant teacher and a surprisingly capable tool for creative photography. By implementing these **Nikon D 40 tips and tricks**, you can overcome its limitations and capture images that rival those from more expensive gear. Focus on mastering aperture and shutter priority, use manual focusing with classic lenses, tame the built-in flash with exposure compensation, and shoot RAW to squeeze every bit of quality from the 6.1-megapixel sensor. Above all, the D40 encourages you to think about light, composition, and technique—skills that no camera spec sheet can replace. Whether you are a beginner or a seasoned shooter revisiting a classic, the D40 still has plenty to offer. Go out, experiment with these tricks, and enjoy the simplicity and joy of pure photography.